



MODEL 5153

IBM
CMT4-2
MODEL 5153

IBM
CMT4-2
MODEL 5153

PRELIMINARY SERVICE CHECKS
ENCLOSED

INDEX


	Page		Page
Block Diagram	24	Photos (Continued)	
Convergence Adjustments	7	CRT Socket Board	18,25
Disassembly Instructions	26	Main Board	8,9,10,19,20,21
GridTrace Location Guide		Power Supply Board	22,23
CRT Socket Board	18	Placement Chart	4
Main Board	11	Resistance Measurements	25
Power Supply Board	22	Schematics	
Miscellaneous Adjustments	7	Notes	3
Parts List	12 thru 17	Terminal Guides	3
Photos		TV	2,27,28,29
AC Input Board	6	Servicing in the Field	26
Cabinet-Rear View	26	Troubleshooting	5,6
CRT Neck Assembly	7	Troubleshooting Aid	5


SAMS Howard W. Sams & Co., Inc.
4300 West 62nd Street, P.O. Box 7092, Indianapolis, Indiana 46206 U.S.A.


The listing of any available replacement part herein does not constitute in any case a recommendation, warranty or guaranty by Howard W. Sams & Co., Inc., as to the quality and suitability of such replacement part. The numbers of these parts have been compiled from information furnished to Howard W. Sams & Co., Inc., by the manufacturers of the particular type of replacement part listed.


Reproduction or use, without express permission, of editorial or pictorial content, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein.

© 1984 Howard W. Sams & Co., Inc.
4300 West 62nd Street, P.O. Box 7092, Indianapolis, Indiana 46206 U.S.A.
Printed in U.S. of America.









CABINET-REAR VIEW DISASSEMBLY INSTRUCTIONS

CHASSIS REMOVAL

Remove two caps from cabinet top and remove two screws holding cabinet to cabinet front. Remove four screws (from bottom) holding cabinet back to cabinet front and remove back.

Disconnect HV anode, CRT socket and ground leads. Remove two screws (from bottom) holding main chassis assembly to cabinet bottom and remove assembly from cabinet.

Remove four screws holding AC power assembly to power supply assembly and main chassis. Remove assembly and disconnect connectors as required. Remove five screws holding power supply assembly to main chassis assembly and cabinet front brace and remove power supply assembly. Remove four screws holding power supply cover

and lift cover off power supply. Remove five screws holding power board to chassis, disconnect connectors and lift board out of chassis.

Remove knobs from cabinet front. Remove three screws holding control indicator assembly to cabinet front and remove assembly from cabinet.

CRT REMOVAL

CAUTION: Set employs CRT with neck assemblies permanently bonded to CRT. **Do Not** attempt to remove neck assemblies from CRT.

Follow "Chassis Removal" procedure and lay set facedown on a soft protective surface. Remove four screws holding CRT to cabinet front and lift CRT out of cabinet. **Do Not** lift CRT by the neck.

SERVICING IN THE FIELD

CRT IMPLOSION PROTECTION AND CLEANING

Implosion protection is an integral part of the picture tube, cleaning accomplished without CRT removal.

FUSE DEVICES

A 4-amp fuse is used for AC line protection. (See photo, Cabinet-Rear View.)

LAMP ACCESSIBILITY

Lamp is accessible after removing cabinet back.

HORIZONTAL OSCILLATOR

Adjustment of the horizontal hold is accomplished by the proper setting of the horizontal hold control (See photo, Cabinet-Rear View.)

WIDTH

The width may be varied by adjusting the width coil. (See Placement Chart.)


FOCUS

The focus may be varied by a focus control. (See photo, Cabinet-Rear View.)

CENTERING

Horizontal centering is accomplished by proper adjustment of the horizontal centering control. (See Placement Chart.)

Vertical centering is accomplished by proper adjustment of the vertical centering control. (See Placement Chart.)



SCHEMATIC NOTES

- Circuitry not used in some versions
 - Circuitry used in some versions
 - See parts list
 - ⊕ Ground
 - ▽ Common tie point
- Waveforms and voltages are taken from ground, unless noted otherwise.
- Waveforms: triggered scope, RGB pattern generator.
- Item numbers in rectangles appear in the alignment/adjustment instructions.
- Supply voltages maintained as shown at input.

Voltages measured with digital meter, with signal applied.

Controls adjusted for normal operation.

Terminal identification may not be found on unit.

Capacitors are 50 volts or less, 5% unless noted.





Electrolytic capacitors are 50 volts or less, 20% unless noted.

Resistors are 1/2W or less, 5% unless noted.

Value in () used in some versions.

Measurements with switching as shown, unless noted.

CM14-2
IBM
MODEL 5153




TOP VIEW

PLACEMENT CHART


RESISTANCE MEASUREMENTS

MEASUREMENTS TAKEN WITH LOW POWER OHMS METER													
ITEM	PIN 1	PIN 2	PIN 3	PIN 4	PIN 5	PIN 6	PIN 7	PIN 8	PIN 9	PIN 10	PIN 11	PIN 12	PIN 13
Q201	325	415	323	418	418	461	0	128	418	458	415	128	415
Q203	135	0	93										
Q253	322	417	417	459	262	197	0	262	324	128	324	128	324
Q402	6470	3410	1628	8120	INF	253	48K	4990	4650	315	4760	17K	INF
											PIN 15	PIN 16	PIN 17
											4760	3460	14K
V901	INF	NC	NC	1	810K	INF	INF	INF	FIL	FIL	4.5		
ITEM	E	B	C		ITEM	E	B	C		ITEM	E	B	C
Q202	0	1.6M	10K		Q502	INF	458	INF		Q561	727	241	93
Q204	1.6M	1091	563		Q503	1.6M	672	INF		Q562	INF	458	INF
Q205	4760	19K	5430		Q504	9910	7970	5630		Q563	1.5M	669	INF
Q206	0	71	1051		Q505	9910	7970	0		Q564	9980	7970	2520
Q251	195	282	93		Q506	810	320	0		Q565	9980	7970	0
Q252	195	197	93		Q531	727	241	93		Q566	805	302	0
Q301	0	3890	1.5M		Q532	INF	458	INF		Q801	0(1)	356(1)	82(1)
Q302	2260	INF	INF		Q533	1.6M	671	INF		Q802	INF(1)	INF(1)	0(1)
Q303	2260	1.5M	0		Q534	10K	7980	5630		Q803	0(1)	561K(1)	INF(1)
Q401	0	265	10K		Q535	10K	7980	0		Q804	6170(1)	1987(1)	542K(1)
Q403	3.8	7.4	5570		Q536	808	330	0		Q805	0(1)	4690(1)	3940(1)
Q501	725	242	93										

(1) Taken with reference to isolated ground.



IBM
MODEL 5153



BLOCK DIAGRAM

TROUBLESHOOTING AID

Note: Waveforms taken with triggered scope, Keyed-Rainbow generator. Schematic voltages measured with digital meter, no signal. Controls adjusted for normal operation.

PICTURE

NO PIC, NO RASTER: Check AC power supply and sources generated from Horizontal Output Transformer (T401). Refer to "Troubleshooting" Power Supply and Horizontal circuits.

NO PIC, HAS RASTER: Check source voltages from Horizontal Output Transformer (T401). Refer to "Troubleshooting" Horizontal circuits.

LOW OR EXCESSIVE BRIGHTNESS: Check Video and Luminance circuits. Refer to "Troubleshooting" Video circuit.

SWEEP

NO RASTER: Check HV rectifier, Part of Horizontal Output Transformer (T401). Refer to "Troubleshooting" Horizontal circuit.

NO VERT DEFLECTION: Refer to "Troubleshooting" Vertical circuit.

POOR VERT LIN OR FOLDOVER: Refer to "Troubleshooting" Vertical circuit.

POOR HORIZ LIN OR FOLDOVER: Refer to "Troubleshooting" Horizontal circuit.

NARROW PICTURE: Refer to "Troubleshooting" Horizontal circuit.

VERT OFF FREQUENCY: Refer to "Troubleshooting" Vertical circuit.

HORIZ OFF FREQUENCY: Refer to "Troubleshooting" Horizontal circuit.

SYNC

NO VERT/HORIZ SYNC: Refer to "Troubleshooting" Sync circuit.

RASTER

YELLOW (NO BLUE): Check Chroma and Blue Output circuits. Refer to "Troubleshooting" Raster circuit.

CYAN (NO RED): Check Chroma and Red Output circuits. Refer to "Troubleshooting" Raster circuit.

MAGENTA (NO GREEN): Check Chroma and Green Output circuits. Refer to "Troubleshooting" Raster circuit.

TROUBLESHOOTING

POWER SUPPLY

Check the AC Line Fuse (F801). If bad, check for possible short at Bridge Rectifier Diodes (D801 thru D804), DC to DC Converter Transformer (T802), Output Transistor (Q801) and SCR Q805. Replace defective components and apply 120 VAC power.

Check for 153V (with respect to isolated ground) at the cathode of Diode D801 and at the collector of Transistor Q801. Check voltages and waveforms (with respect to isolated ground) at pin 12 of Transformer T802, base of Transistor Q801 and the anode of SCR Q805. Check for 115V at the cathode of Diode D815. If the 115V is missing, check Transformer T802, Transistor Q801, SCR Q805 and associated components. Check sources that are developed from the Horizontal Output Transformer (T401), refer to the "Power Supply" section of this Troubleshooting guide.

VERTICAL

No vertical deflection. Inject a vertical signal at pin 2 of the Sync Processor IC (Q402). If vertical deflection returns, check voltages, waveforms and components associated with pins 2, 3, 4, 6, 7 and 8 of IC Q402 and associated circuitry. If the vertical deflection does not return, check voltages, waveforms and components associated with Vertical Driver Transistor (Q301), Vertical Output Transistor (Q302 and Q303), Electrolytic C315 and the vertical winding on the deflection yoke.

Vertical linearity or foldover problems can be caused by vertical feedback and bias circuits. Check the condition of Diodes D301 thru D306, Electrolytic C315, Side Pincushion Transformer (T402) and associated circuitry.

CMT4-2
IBM
MODEL 5153

TROUBLESHOOTING (Continued)

SYNC

No vertical sync. Check for vertical pulses at pin 9 of P2, check voltages, waveforms and components associated with pins 2 thru 8 of the Sync Processor IC (Q402).

No horizontal sync. Check for horizontal pulses at pin 8 of P2, check voltages, waveforms and components associated with the Horizontal Amp Transistors (Q204 and Q205) and pins 13 thru 16 of IC Q402.

RASTER

Check the CRT and CRT voltages and waveforms.

Raster is magenta (No green). Check voltages, waveforms and components associated with Transistors Q535, Q534, Q532, Q533 and pin 4 of the CRT socket.

Raster is yellow (No blue). Check voltages, waveforms and components associated with Transistors Q505, Q504, Q502, Q503 and pin 9 of the CRT socket.

Raster is cyan (No red). Check voltages, waveforms and components associated with Transistors Q565, Q564, Q562, Q563 and pin 6 of the CRT socket.

Raster has a keystone shape. Check the deflection yoke.

Raster has a pincushion shape. Check the Side Pincushion Transformer (T402) and associated circuitry.

Raster has height or width problems. Refer to the "Vertical", "Horizontal" and "Power Supply" sections of this Troubleshooting guide.

HORIZONTAL

Check for 115V at the collector of the Horizontal Output Transistor (Q403). If 115V is missing, check for 115V at TP91, at both ends of Coil L404 and at pins 7 and 8 of the Horizontal Output Transformer (T401). If the 115V is missing at TP91, refer to the "Power Supply".

Inject a horizontal signal at the base of Transistor Q403. If the high voltage returns, check voltages, waveforms and

components associated with pins 9 thru 12 of the Sync Processor IC (Q402), Horizontal Driver Transistor (Q401) and associated components. If the high voltage does not return, check voltages, waveforms and components associated with Transistor Q403 and Transformer T401.

The high voltage rectifier is a part of Transformer T401 assembly and may be bad. Check for possible shorts at the B + sources that are developed from Transformer T401 that could be loading down the horizontal circuits. Check for 207V at the cathode of Diode D405, 43.2V at the cathode of Diode D307 and 13.61V at the cathode of Diode D404.

Poor horizontal linearity or foldover problems may be caused by the condition of Capacitors C422 and C415, Side Pincushion Transformer (T402) and associated circuitry.

VIDEO

No characters appear on the screen of the CRT. Check for 5.01V at pin 14 of the Inverter ICs (Q201 and Q253) and check the Regulator IC (Q203).


Inject a video signal at the base of the Blue Amp Transistor (Q506) and check for blue picture on the CRT. If there is no video on the CRT, check voltages, waveforms and components associated with Transistors Q506, Q502, Q503, Q504 and Q505.

Inject a video signal at the base of the Green Amp Transistor (Q536) and check for green picture on the CRT. If there is no video on the CRT, check voltages, waveforms and components associated with Transistors Q536, Q532, Q533, Q534 and Q535.

Inject a video signal at the base of the Red Amp Transistor (Q566) and check for red picture on the CRT. If there is no video on the CRT, check voltages, waveforms and components associated with Transistors Q566, Q562, Q563, Q564 and Q565.



If video appears on the screen of the CRT, check voltages, waveforms and components associated with Transistors Q206, Q251, Q252 and ICs Q201 and Q253. Check the CRT and CRT voltages and waveforms.

Video has retrace lines, check voltages and components associated with the Blanking Transistor (Q202).



AC INPUT BOARD

A Howard W. Sams CIRCUITRACE® Photo




A Howard W. Sams CIRCUITRACE® Photo

POWER SUPPLY BOARD

IBM
MODEL 5153

POWER SUPPLY BOARD GridTrace LOCATION GUIDE

C802	C-8	C831	I-5	F801	D-4	R809	H-13
C803	F-3	D801	F-3	L801	G-12	R810	B-12
C804	F-3	D802	I-3	L802	D-6	R811	I-13
C805	G-3	D803	G-3	L803	I-5	R812	F-8
C806	H-3	D804	H-3	L805	E-5	R813	H-9
C807	B-7	D805	C-10	L806	C-11	R814	G-8
C808	B-5	D806	F-11	Q801	C-13	R815	I-8
C809	E-10	D807	F-9	Q802	I-12	R816	I-9
C811	G-11	D808	G-10	Q803	I-13	R817	I-8
C812	H-8	D809	F-10	Q804	J-9	R818	J-7
C813	G-9	D810	H-9	Q805	J-14	R820	H-8
C814	J-9	D811	G-9	R	I-9	R821	G-13
C815	G-8	D812	G-8	R801	H-3	R823	I-11
C817	E-6	D813	H-8	R802	C-10	R824	J-12
C818	G-5	D814	I-8	R803	A-12	R825	J-11
C821	H-10	D815	E-5	R804	F-12	R851	J-7
C822	G-13	D817	G-13	R805	F-11	R890	J-1
C824	D-2	D820	I-10	R806	H-11	T801	F-2
C825	J-12	D822	J-10	R807	H-12	T802	D-7
C826	I-11	D823	E-11	R808	G-11	X	H-7



POWER SUPPLY BOARD

A Howard W. Sams | GRIDTRACE™ Photo

MISCELLANEOUS ADJUSTMENTS

B + ADJUSTMENT

Connect a DC meter to TP91, low side to ground. Apply power to Monitor. Adjust B+ Adjust Control (R851) for +115V.

HORIZONTAL HOLD ADJUSTMENT

Connect a RGB video pattern generator to the Monitor. Use a color bar pattern. Connect a .1µF Capacitor from TP22 to ground. Adjust Horizontal Hold Control (R409) until the bars stop (in sync) or slowly float across the screen. Remove the .1µF Capacitor.

HORIZONTAL AND VERTICAL CENTERING

Connect a RGB video pattern generator to the Monitor. Use a color bar pattern. Adjust Horizontal Center Control (R434) for best horizontal centering of the raster. Adjust Vertical Center Control (R336) for best vertical centering of the raster.

HORIZONTAL PHASE CONTROL

Adjust Horizontal Phase Control (R413) to place the cursor at the left edge of the raster.

PURITY ADJUSTMENT

Degauss the CRT, if necessary. Set the Blue (R517) and Green (R547) Background Controls to MINIMUM. Advance the Red Background Control (R577) to produce a red raster. Loosen the deflection yoke and slide it back against the Purity/Convergence Assembly. Adjust the Purity Magnets to produce a vertical red stripe at the center of the screen. Slide the deflection yoke forward to produce uniform red

raster. Check for pure blue and green screens by advancing the Blue (R517) and Green (R547) Background Controls one at a time.


COLOR TEMPERATURE ADJUSTMENT

Set the Blue (R506) and Green (R536) Drive Controls to midrange. Set the Red (R577), Blue (R517) and Green (R547) Background Controls to MINIMUM. Set Service Switch (S301) to Service position. From MINIMUM position adjust Screen Control (R999B) to obtain a dim line of a predominate color. Adjust the two background controls of the least predominate colors to obtain a dim white line. Set Service Switch to Normal. Adjust the Blue (R506) and Green (R536) Drive Controls for a black and white picture

CONVERGENCE ADJUSTMENTS


Connect a RGB video pattern generator to the antenna terminals and tune in a dot pattern. Adjust Four-pole Convergence Magnets to converge the red and blue dots at the center of the screen. Adjust Six-pole Convergence Magnets to converge the red/blue dots over the green dots at the center of the screen.

Tune in a crosshatch pattern. Remove the rubber wedges between the deflection yoke and CRT. Tilt the deflection yoke up or down to converge the vertical lines at the top and bottom of the screen and the horizontal lines at the right and left sides of the screen. Tilt the deflection yoke to the right or left to converge the horizontal lines at the top and bottom of the screen and the vertical lines at the right and left sides of the screen. Repeat convergence procedure if necessary to obtain the best overall convergence. Replace the rubber wedges.




CRT NECK ASSEMBLY


CMT4-2
IBM
MODEL 5153



IBM
MODEL 5153

IBM
CMT4-2 MODEL 5153





IBM
MODEL 5153

CRT SOCKET BOARD GridTrace LOCATION GUIDE

C215	C-3	D510	D-4	R543	D-11	R952	I-11
C509	G-3	D537	F-13	R544	B-9	R953	I-10
C510	E-2	D540	B-12	R545	E-12	R954	E-2
C539	I-12	D567	D-10	R547	B-11	R955	G-11
C540	I-13	D570	B-8	R573	B-6	R956	E-10
C569	C-7	R513	B-5	R574	C-13	TP54B	D-2
C570	G-11	R514	C-5	R575	E-12	TP54G	H-12
C951	I-9	R515	C-2	R577	B-7	TP54R	F-11
C952	I-11	R517	B-4	R951	H-1	TP402	C-1
D507	D-3						

MAIN BOARD GridTrace LOCATION GUIDE

C201	E-5	C537	K-4	Q253	B-9	R324	D-24	R568	M-3
C202	D-8	C538	N-4	Q301	J-10	R325	C-21	R569	E-5
C203	C-11	C541	I-4	Q302	H-15	R331	G-22	R570	G-3
C204	E-14	C565	I-3	Q303	H-12	R332	G-25	R571	H-2
C205	B-2	C566	L-2	Q401	I-19	R334	G-20	R572	I-3
C206	H-10	C567	K-2	Q402	L-12	R335	G-2	R579	M-1
C208	P-7	C568	Q-1	Q501	E-5	R336	D-22	R580	D-5
C209	Q-26	C571	I-2	Q502	I-7	R401	K-15	R581	N-3
C210	B-4	D201	E-16	Q503	I-7	R402	L-14	R582	G-4
C211	B-6	D202	D-16	Q504	N-7	R403	L-13	S301	Q-9
C212	F-12	D205	R-5	Q505	M-7	R404	L-13	T401	J-22
C213	J-12	D209	A-5	Q506	F-8	R405	K-14	T402	C-25
C216	A-3	D211	J-3	Q531	D-9	R406	N-12	T403	O-22
C217	D-11	D301	I-12	Q532	I-4	R407	P-12	TP21	B-4
C218	D-5	D302	I-13	Q533	I-4	R408	Q-13	TP22	J-11
C301	O-11	D303	I-13	Q534	N-5	R409	Q-12	TP43	I-3
C302	N-11	D304	H-17	Q535	M-4	R410	M-14	TP44	O-25
C303	L-10	D305	H-16	Q536	F-5	R411	P-13	TP52B	J-7
C304	L-11	D306	J-15	Q561	C-11	R412	K-16	TP52G	J-4
C305	L-10	D307	M-19	Q562	I-2	R413	Q-14	TP52R	J-2
C306	N-10	D309	G-24	Q563	I-2	R414	P-14	TP91	R-8
C307	O-11	D310	P-10	Q564	N-2	R415	N-15	TPG1	Q-2
C308	P-11	D401	K-13	Q565	M-2	R416	K-21		
C309	K-10	D402	P-14	Q566	F-2	R417	J-21		
C310	H-18	D403	P-13	R203	D-17	R418	G-22		
C311	F-16	D404	M-16	R204	E-17	R419	I-26		
C313	H-17	D405	Q-25	R205	H-8	R420	I-25		
C314	I-15	D407	G-19	R206	E-8	R421	P-25		
C315	F-24	D408	G-19	R207	D-4	R423	J-23		
C316	B-23	D411	Q-4	R208	C-2	R425	M-18		
C318	H-23	D412	Q-4	R209	D-10	R426	P-16		
C319	F-23	D501	B-12	R213	Q-6	R430	Q-17		
C321	G-13	D502	E-11	R214	R-7	R431	Q-4		
C401	L-15	D504	G-8	R216	B-14	R434	D-20		
C402	K-14	D505	L-8	R218	F-13	R435	N-18		
C403	J-14	D506	L-6	R219	C-9	R436	Q-5		
C404	M-13	D509	L-7	R220	B-2	R437	R-5		
C405	O-12	D513	I-8	R221	C-5	R438	Q-5		
C406	N-13	D531	B-12	R222	B-3	R439	Q-19		
C407	O-13	D532	E-10	R223	B-6	R440	Q-19		
C408	P-13	D534	G-5	R224	J-12	R501	C-4		
C409	N-13	D535	L-5	R225	J-12	R502	D-2		
C410	Q-13	D536	L-4	R226	K-12	R503	D-4		
C411	P-15	D539	L-5	R231	C-13	R504	C-10		
C412	J-20	D543	I-6	R232	B-15	R506	F-9		
C413	J-19	D547	I-4	R233	D-15	R507	C-12		
C414	K-20	D561	B-13	R252	D-9	R508	M-8		
C417	O-19	D562	E-10	R257	A-8	R509	B-11		
C418	L-24	D564	G-2	R258	B-7	R510	G-7		
C419	M-25	D565	L-3	R261	D-4	R511	H-7		
C420	K-24	D566	Q-2	R263	E-7	R512	I-8		
C421	I-25	D569	L-3	R264	B-11	R519	L-6		
C422	H-25	L301	M-11	R302	K-11	R520	C-10		
C423	R-25	L302	L-19	R303	Q-12	R521	N-8		
C424	R-20	L401	H-20	R304	O-9	R531	C-4		
C425	C-22	L403	F-25	R305	M-10	R532	E-2		
C426	C-21	L404	Q-18	R306	R-9	R533	E-4		
C428	L-17	L501	K-8	R307	O-11	R534	D-8		
C429	M-17	L531	L-6	R308	Q-11	R536	F-7		
C430	Q-7	L561	K-3	R309	R-10	R537	E-9		
C431	P-3	L808	P-18	R310	N-11	R538	L-5		
C432	P-3	P/J201	D-3	R311	O-10	R539	D-8		
C433	K-19	P/J202	D-12	R312	N-9	R540	G-4		
C434	R-18	P/J203	P-6	R313	F-13	R541	H-4		
C435	O-15	P/J204	I-16	R314	H-12	R542	I-6		
C436	Q-3	P/J401	I-24	R315	G-16	R549	L-4		
C471	O-16	Q201	D-6	R316	F-15	R550	C-8		
C505	I-7	Q202	D-18	R317	I-13	R551	M-5		
C506	L-7	Q203	G-11	R318	G-14	R561	B-4		
C507	K-7	Q204	B-5	R319	J-17	R562	E-2		
C508	N-6	Q205	K-12	R320	J-18	R563	E-4		
C511	I-6	Q206	D-10	R321	L-18	R564	D-6		
C535	I-5	Q251	D-14	R322	F-18	R566	F-3		
C536	L-4	Q252	D-14	R323	E-19	R567	E-4		

CMT4-2
MODEL 5153
IBM

When ordering parts, state Model, Part Number, and Description

SEMICONDUCTORS (Select replacement transistor for best results)

ITEM No.	TYPE No.	MFGR. PART No.	REPLACEMENT DATA						ZENITH PART No.
			GENERAL ELECTRIC PART No.	MOTOROLA PART No.	NEW-TONE NTE PART No.	PHILIPS ECG PART No.	RCA PART No.	WORKMAN PART No.	
D201,2	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D205	V06C		GE-504A	1N4003	NTE116	ECG116	SK3311	WEP156	212-76-02
D209	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D211	HZ-7B1		GEZD-6.8	1N5235B	NTE5014A	ECG5014A	SK6AB/5014A	WEP1415/5014	103-Z9009
	HZ-7B		GEZD-6.8	1N5235B	NTE5014A	ECG5014A	SK6AB/5014A	WEP1415/5014	103-Z9009
D301 thru D303	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D304,5	V09C		GE-511		NTE552	ECG552	SK5002	WEP172/506	103-287
D306	V06E		GE-504A	1N4005	NTE116	ECG116	SK3017B	WEP158/116	212-76-02
D307	V09G		GE-511		NTE552	ECG552	SK9000/552	WEP172/506	103-287
D309	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D310	HZ11A		GEZD-11	1N5241B	NTE5020A	ECG5020A	SK11A/5020A	WEP1421/5020	103-279-20
D401 thru D403	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D404	V09E		GE-511		NTE552	ECG552	SK9000/552	WEP172/506	103-287
D405	V09C		GE-511		NTE552	ECG552	SK5002	WEP172/506	103-287
D407,8	V09C		GE-511		NTE552	ECG552	SK5002	WEP172/506	103-287
D411,12	V06C		GE-504A	1N4003	NTE116	ECG116	SK3311	WEP156	212-76-02
D501,2	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D504,5	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D506	V06C		GE-504A	1N4003	NTE116	ECG116	SK3311	WEP156	212-76-02
D507	V09C		GE-511		NTE552	ECG552	SK5002	WEP172/506	103-287
D509,10	V06C		GE-504A	1N4003	NTE116	ECG116	SK3311	WEP156	212-76-02
D513	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D531,32	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D534,35	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D536	V06C		GE-504A	1N4003	NTE116	ECG116	SK3311	WEP156	212-76-02
D537	V09C		GE-511		NTE552	ECG552	SK5002	WEP172/506	103-287
D539,40	V06C		GE-504A	1N4003	NTE116	ECG116	SK3311	WEP156	212-76-02
D543	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D547	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D561,62	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D564,65	1S2076		GE-514	1N4935	NTE519	ECG519	SK3100/519	WEP925/519	103-131
D566	V06C		GE-504A	1N4003	NTE116	ECG116	SK3311	WEP156	212-76-02
D567	V09C		GE-511		NTE552	ECG552	SK5002	WEP172/506	103-287

PARTS LIST AND DESCRIPTION (Continued)

When ordering parts, state Model, Part Number, and Description

FUSE DEVICES

ITEM NO.	DESCRIPTION	MFGR. PART NO.		NOTES
		DEVICE	HOLDER	
F801	4A @ 250V Slow-Blow			

TRANSFORMER (DC-DC Converter)

ITEM No.	RATING			REPLACEMENT DATA		
				MFGR. PART No.	THORDARSON PART No.	NOTES
	PRI.	SEC. 1	SEC. 2	TPW-246 (1)		
	400V p-p @ 412mA DC	200V p-p @ 479mA DC	40V p-p @ 8.89mA DC			
T802	SEC. 3	SEC. 4	SEC. 5			
	14V p-p @ 64mA DC					

(1) Number on unit.

MISCELLANEOUS

ITEM No.	PART NAME	MFGR. PART No.	NOTES
D203	LED	8654275 (1)	Power, FLV310, Grn (2.07V @ 10.78mA)
DG1	Degaussing Coll	8654275 (1)	
L806	Ferrite Bead		AC Power Normal/Service 370RKB2-TC14 Main Board Power Supply Board CRT Socket Board AC Input Board Includes Cable and Connectors
P800	Power Cord	8529158	
S1	Switch		
S301	Switch		
V901	CRT	8529290 (1)(2)	
	P.C. Board		
	P.C. Board		
	P.C. Board		
	P.C. Board		
	Signal Cable	8529334 (1)	

(1) Restricted Availability.

(2) Includes CRT and Yoke.

CABINET & CABINET PARTS (When ordering specify model, chassis & color)

ITEM	PART No.	ITEM	PART No.
Front Cover (Includes Top, Bottom and Power Supply Brackets).	8529285 (1)	Plug, Cover Screw	8529287
Rear Cover	8529286 (1)	Knob, Brightness	8529288
		Knob, Contrast	8529289
		Knob, Power On/Off	

(1) Restricted Availability.

MODEL 5153

IBM

PARTS LIST AND DESCRIPTION (Continued)

When ordering parts, state Model, Part Number, and Description

RESISTORS (Power and Special)

ITEM No.	RATING	REPLACEMENT DATA		
		MFGR. PART No.	NEW-TONE PART No.	WORKMAN PART No.
R213	2.2 1/2W Fusible			
R214	2.2 1/2W Fusible			
R320	10 1/2W Fusible			
R401	6800 5% 3W Metal Oxide			
R416	4700 5% 3W Metal Oxide			
R418	3.9 5% 5W WW		5W3D9	
R421	2.2 1/2W Fusible			
R425	2.2 1/2W Fusible			
R430	10K 2% 1/4W Carbon Film		QW310	22-2253
R508	2400 5% 5W WW			
R521	56 1/2W Fusible			
	10 1/2W Fusible			
R538	2400 5% 5W WW			
R551	56 1/2W Fusible			
	10 1/2W Fusible			
R568	2400 5% 5W WW			
R581	56 1/2W Fusible			
	10 1/2W Fusible			
R801	3.3 5% 10W WW		10W3D3	
R802	180 5% 5W WW		5W118	
R803	56K 5% 3W Metal Oxide			
R805	16 5% 5W WW			
R808	2.2 1/2W Fusible			
R817	1200 1% 1/4W Carbon Film			
R818	2000 1% 1/4W Carbon Film			
R823	10 1/2W Fusible			
R890	PTC 3.7 Cold			FR605

COILS (RF-IF)

ITEM No.	FUNCTION	MFGR. PART No.
L301	RF Choke (5uH)	
L302	RF Choke	
L401	RF Choke (3.3mH)	
L404	RF Choke (18uH)	
L501	RF Choke (10uH)	
L531	RF Choke (10uH)	
L561	RF Choke (10uH)	

ITEM No.	FUNCTION	MFGR. PART No.
L801	RF Choke	
L802	RF Choke	
L803	RF Choke	
L804	AC Line Choke	
L805	RF Choke	
L808	RF Choke	
T801	AC Line Choke	

COILS & TRANSFORMERS (Sweep Circuits)

ITEM No.	FUNCTION	REPLACEMENT DATA		
		MFGR. PART No.	OTHER IDENTIFICATION	THORDARSON PART No.
DY	Yoke 90° Horiz 2.02mH	8529290 (2)(3)	89235100 (1)	
L403	Vert 134mH			
T401	Width		TWH104 (1)	
T402	Horiz Driver		TLN114 (1)	
T403	Side Pincushion		TPC2009A (1)	
	Horiz Output		TFB150A (1)	

- (1) Number on unit.
- (2) Includes CRT and Yoke.
- (3) Restricted Availability.

PARTS LIST AND DESCRIPTION (Continued)

When ordering parts, state Model, Part Number, and Description

SEMICONDUCTORS (Select replacement transistor for best results)

ITEM No.	TYPE No.	MFGR. PART No.	REPLACEMENT DATA						
			GENERAL ELECTRIC PART No.	MOTOROLA PART No.	NEW-TONE NTE PART No.	PHILIPS ECG PART No.	RCA PART No.	WORKMAN PART No.	ZENITH PART No.
D569,70 D801 D802 D803 D804	V06C		GE-504A	1N4003	NTE116	ECG116	SK3311	WEP156	212-76-02
D805 D806 D807 D808 D809			GE-511 GE-511 GE-511		NTE552 NTE552 NTE552	ECG552 ECG552 ECG552	SK9000/552 SK9000/552 SK9000/552	WEP172/506 WEP172/506 WEP172/506	103-287 103-287 103-287
D810 D811 D812 D813 D814			GE-511 GE-511		NTE552 NTE552	ECG552 ECG552	SK9000/552 SK9000/552	WEP172/506 WEP172/506	103-287 103-287
D815 D817 D820 D822 D823			GE-511		NTE552	ECG552	SK9000/552	WEP172/506	103-287
Q201 Q202 Q203 Q204	SN74S05N HD74S05 2SC458C HA17805,P 2SC458C		GE-210 GEVR-102 GE-210	2N4401* MC7805CT 2N4401*	NTE85 NTE960 NTE85	ECG74S05 ECG74S05 ECG85 ECG960 ECG85	SK3124A/289A SK3591/960 SK3124A/289A	WEP910/289 WEP910/289 WEP910/289	121-972* 221-Z9043 121-972*
Q205 Q206 Q251,52 Q253	2SA844D,E 2SC458C 2SC458C SN74S05N		GE-65 GE-210 GE-210	2N5679* 2N4401* 2N4401*	NTE234 NTE85 NTE85	ECG234 ECG85 ECG85	SK3247/234 SK3124A/289A SK3124A/289A	WEP907/234 WEP910/289 WEP910/289	121-Z9005 121-972* 121-972*
Q301 Q302 Q303 Q401 Q402	HD74S05 2SC1921 2SD1136C 2SB861C 2SC2611BK HA11235		GE-222* GE-375 GE-232	MPSU10* MJE340	NTE74S05 NTE399 NTE54 NTE398 NTE157 NTE1550	ECG74S05 ECG399 ECG54 ECG398 ECG157 ECG1550	SK9352/399 SK9118/375 SK9363/398 SK3747/157 SK9249/1550	WEP750 WEP763/375 WEP61/157	121-Z9045* 121-Z9106 121-Z9115 121-Z9016

**IBM
MODEL 5153
CMT4-2**

14 PARTS LIST AND DESCRIPTION (Continued)

When ordering parts, state Model, Part Number, and Description

SEMICONDUCTORS (Select replacement transistor for best results)

ITEM No.	TYPE No.	MFGR. PART No.	REPLACEMENT DATA						
			GENERAL ELECTRIC PART No.	MOTOROLA PART No.	NEW-TONE NTE PART No.	PHILIPS ECG PART No.	RCA PART No.	WORKMAN PART No.	ZENITH PART No.
Q403	2SD898B		GE-210 GE-251 GE-86	BU208	NTE89	ECG89	SK9119/89	WEP89/89	121-Z9112
Q501	2SC458C			2N4401*	NTE85	ECG85	SK3124A/289A	WEP910/289	121-972*
Q502	2SC1514			TIP50	NTE376	ECG376	SK9362/376	WEP779/198	121-Z9028
Q503	2SC1906			MP56543*	NTE107	ECG107	SK3293/107	WEP923/316*	121-522*
Q504	2SD757C,D								
Q505	2SB717C,D								
Q506	2SA844D,E		GE-65 GE-210 GE-251 GE-86	2N5679*	NTE234	ECG234	SK3247/234	WEP907/234	121-Z9005
Q531	2SC458C			2N4401*	NTE85	ECG85	SK3124A/289A	WEP910/289	121-972*
Q532	2SC1514			TIP50	NTE376	ECG376	SK9362/376	WEP779/198	121-Z9028
Q533	2SC1906			MP56543*	NTE107	ECG107	SK3293/107	WEP923/316*	121-522*
Q534	2SD757C,D								
Q535	2SB717C,D								
Q536	2SA844D,E		GE-65 GE-210 GE-251	2N5679*	NTE234	ECG234	SK3247/234	WEP907/234	121-Z9005
Q561	2SC458C			2N4401*	NTE85	ECG85	SK3124A/289A	WEP910/289	121-972*
Q562	2SC1514			TIP50	NTE376	ECG376	SK9362/376	WEP779/198	121-Z9028
Q563	2SC1906			MP56543*	NTE107	ECG107	SK3293/107	WEP923/316*	121-522*
Q564	2SD757C,D								
Q565	2SB717C,D								
Q566	2SA844E		GE-65	2N5679*	NTE234	ECG234	SK3247/234	WEP907/234	121-Z9005
Q801	2SD1185						SK3111		
Q802	2SB739C		GE-48 GE-268 GE-269	2N2906A	NTE294	ECG294	SK3841/294	WEP916/294	121-Z9067
Q803	2SC1213C			2N4401*	NTE289A	ECG289A	SK3122	WEP910/289	121-Z9065
Q804	2SA1029C			2N4403	NTE290A	ECG290A	SK3114A/290A	WEP911/290A	121-Z9003
Q805	CW12B								

* Lead configuration may vary from original.

WIRING DATA

High Voltage Lead Use BELDEN No. 9867 (30 KV) or 8866 (40 KV)
Shielded Hook-up Wire Use BELDEN No. 8401 or 8421 (Single-Conductor)
General-use Unshielded Hook-up Wire Use BELDEN No. 8208 (Two-Conductor)
8529 (Solid) Available in 13 Colors
8522 (Stranded) Available in 13 Colors

PARTS LIST AND DESCRIPTION (Continued)

When ordering parts, state Model, Part Number, and Description

ELECTROLYTIC CAPACITORS

Item numbers not listed are normally available at local distributors.

ITEM No.	RATING			MFGR. PART No.
C306	2.2	25V	10%	

ITEM No.	RATING			MFGR. PART No.

CAPACITORS

Item numbers not listed are normally available at local distributors.

ITEM No.	RATING			MFGR. PART No.
C824	.1	125VAC	10%	
C827	.1	125VAC		
C828	.1	125VAC		


ITEM No.	RATING			MFGR. PART No.
C829	.01	125VAC		
C830	.01	125VAC		

CONTROLS (All wattages 1/2 watt, or less, unless listed)

ITEM NO.	FUNCTION	RESISTANCE	MFGR. PART NO.	NOTES
R210	Brightness	100K		
R215	Brightness	50K		
R306	Contrast	500		
R309	Vert Size	500		
R336	Vert Hold	5000		
R409	Vert Center	5000		
R413	Horiz Hold	5000		
R434	Horiz Phase	5000		
R506	Horiz Center	500		
R517	Blue Drive	1000		
R536	Blue Background	50K		
R547	Green Drive	1000		
R566A	Green Background	50K		
R577	Red Drive	1000		
R851	Red Background	50K		
R999A	B+ Adjust	500		
B	Focus	(18)		
	Screen			

(18) R999A and B part of T403.

IBM
MODEL 5153



CRT SOCKET BOARD

PRELIMINARY SERVICE CHECKS

This data provides the user with a time-saving service tool which is designed for quick isolation and repair of computer malfunctions.

Check all interconnecting cables for good connection and correct hookup before making service checks.

DISASSEMBLY INSTRUCTIONS

CHASSIS REMOVAL

Remove two caps from cabinet top and remove two screws holding cabinet to cabinet front. Remove four screws (from bottom) holding cabinet back to cabinet front and remove back.

Disconnect HV anode, CRT socket and ground leads. Remove two screws (from bottom) holding main chassis assembly to cabinet bottom and remove assembly from cabinet.

Remove four screws holding AC power assembly to power supply assembly and main chassis. Remove assembly and disconnect connectors as required.

Remove five screws holding power supply assembly to main chassis assembly and cabinet front brace and remove power supply assembly.

Remove four screws holding power supply cover and lift cover off power supply. Remove five screws holding power board to chassis, disconnect connectors and lift board out of chassis.

Remove knobs from cabinet front. Remove three screws holding control indicator assembly to cabinet front and remove assembly from cabinet.

CRT REMOVAL

CAUTION: Set employs CRT with neck assemblies permanently bonded to CRT. **Do Not** attempt to remove neck assemblies from CRT.

Follow "Chassis Removal" procedure and lay set facedown on a soft protective surface. Remove four screws holding CRT to cabinet front and lift CRT out of cabinet. **Do Not** lift CRT by the neck.

SAMSTM **Howard W. Sams & Co., Inc.**
4300 West 62nd Street, P.O. Box 7092, Indianapolis, Indiana 46206 U.S.A.

The listing of any available replacement part herein does not constitute in any case a recommendation, warranty or guaranty by Howard W. Sams & Co., Inc., as to the quality and suitability of such replacement part. The numbers of these parts have been compiled from information furnished to Howard W. Sams & Co., Inc., by the manufacturers of the particular type of replacement part listed.

Reproduction or use, without express permission, of editorial or pictorial content, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein.

© 1984 Howard W. Sams & Co., Inc.
4300 West 62nd Street, P.O. Box 7092, Indianapolis, Indiana 46206 U.S.A.
Printed in U.S. of America.

84CF14927 **DATE 9-84**

IBM
CMT4-2 MODEL 5153

PRELIMINARY SERVICE CHECKS (Continued)

SERVICE CHECKS

SEE INTERCONNECTING DIAGRAM, PLACEMENT CHART, AND PHOTOS TO MATCH THE NUMBER IN THE CIRCLES WITH THOSE IN THE FOLLOWING DATA FOR SERVICE CHECKS TO BE PERFORMED.

- 1

POWER SUPPLY

(A) Check AC Fuse (F801).

(B) If Fuse F801 is bad, check Bridge Rectifier Diodes (D801 thru D804).

(C) Check for 120VAC at the output connector of the AC Input Board.

(D) If the 120VAC is missing, check Coil L804.

(E) Disconnect DC output connector from Power Board.

(F) Check for 115V across the DC output connector on the Power Board. If 115V is missing, check the Power Board by substitution.

(G) Check the adjustment of B+ Adjust Control (R851), see Miscellaneous Adjustments.
- 2

NO RASTER

(A) Check the CRT HV Anode voltage with a HV probe.
- 3

NO VIDEO

(A) Check RGB connector P2 at the Computer and P201 at the Monitor for bad connections.

(B) Check the voltages on the CRT socket.
- (B) If the HV is missing, check the Horizontal Output Transistor (Q403).

(C) Check for 115V at the collector of Transistor Q403.

(D) If the 115V is missing, check Coils L404, L808, and pin 7 and 8 of the Horizontal Output Transformer (T403) for continuity.

(E) Check the Sync Processor IC (Q402) by substitution.

(F) Check the Service Switch (S301).

(G) Check the CRT with a CRT tester.

TEST EQUIPMENT AND TOOLS

TEST EQUIPMENT

Digital Volt/Ohm Meter
High Voltage Probe
CRT Tester


TOOLS

Phillips Screwdriver
¼" Nut Driver
Soldering Iron
Desoldering Tool

PARTS LIST AND DESCRIPTION

ITEM	PART NO.	DESCRIPTION
D801 thru D804		Bridge Rectifiers
F801		4A Fuse
L404		RF Choke
L804		AC Line Choke
L808		RF Choke
Q402		Sync Processor IC
Q403		Horiz Output Transistor
R851		B+ Adjust Control
S301		Service Switch
T403		Horiz Output Transformer

PRELIMINARY SERVICE CHECKS (Continued)



CHASSIS-TOP VIEW

PRELIMINARY SERVICE CHECKS (Continued)



POWER SUPPLY BOARD

PRELIMINARY SERVICE CHECKS (Continued)

MISCELLANEOUS ADJUSTMENTS

B+ ADJUSTMENT

Connect a DC meter to TP91, low side to ground. Apply power to Monitor. Adjust B+ Adjust Control (R851) for +115V.

HORIZONTAL HOLD ADJUSTMENT

Connect a RGB video pattern generator to the Monitor. Use a color bar pattern. Connect a .1μF Capacitor from TP22 to ground. Adjust Horizontal Hold Control (R409) until the bars stop (in sync) or slowly float across the screen. Remove the .1μF Capacitor.

HORIZONTAL AND VERTICAL CENTERING

Connect a RGB video pattern generator to the Monitor. Use a color bar pattern. Adjust Horizontal Center Control (R434) for best horizontal centering of the raster. Adjust Vertical Center Control (R336) for best vertical centering of the raster.

HORIZONTAL PHASE CONTROL

Adjust Horizontal Phase Control (R413) to place the cursor at the left edge of the raster.

PURITY ADJUSTMENT

Degauss the CRT, if necessary. Set the Blue (R517) and Green (R547) Background Controls to MINIMUM. Advance the Red Background Control (R577) to produce a red raster. Loosen the deflection yoke and slide it back against the Purity/Convergence Assembly. Adjust the Purity Magnets to produce a vertical red stripe at the center of the screen. Slide the deflection yoke forward to produce uniform red

raster. Check for pure blue and green screens by advancing the Blue (R517) and Green (R547) Background Controls one at a time.


COLOR TEMPERATURE ADJUSTMENT

Set the Blue (R506) and Green (R536) Drive Controls to midrange. Set the Red (R577), Blue (R517) and Green (R547) Background Controls to MINIMUM. Set Service Switch (S301) to Service position. From MINIMUM position adjust Screen Control (R999B) to obtain a dim line of a predominate color. Adjust the two background controls of the least predominate colors to obtain a dim white line. Set Service Switch to Normal. Adjust the Blue (R506) and Green (R536) Drive Controls for a black and white picture

CONVERGENCE ADJUSTMENTS

Connect a RGB video pattern generator to the antenna terminals and tune in a dot pattern. Adjust Four-pole Convergence Magnets to converge the red and blue dots at the center of the screen. Adjust Six-pole Convergence Magnets to converge the red/blue dots over the green dots at the center of the screen.

Tune in a crosshatch pattern. Remove the rubber wedges between the deflection yoke and CRT. Tilt the deflection yoke up or down to converge the vertical lines at the top and bottom of the screen and the horizontal lines at the right and left sides of the screen. Tilt the deflection yoke to the right or left to converge the horizontal lines at the top and bottom of the screen and the vertical lines at the right and left sides of the screen. Repeat convergence procedure if necessary to obtain the best overall convergence. Replace the rubber wedges.




AC INPUT BOARD

CMT4-2
MODEL 5153
IBM

39


CRT VOLTAGES
PIN 1 5KV
2 NC
3 NC
4 0V
5 15.44V
6 122V
7 322V
8 126V
9 FIL
10 FIL
11 127V
12 NC

INTERCONNECTING DIAGRAM




IBM
MODEL 5153

CRT BOARD



MAIN BOARD



PLACEMENT CHART

PRELIMINARY SERVICE CHECKS (Continued)

